

## Finding the right String Saver

First you will need to determine what type of String Saver you need.

6 different categories:

- SS Originals for guitar
- SS Originals for bass
- SS Originals for tune-o-matics
- SS Classic for guitar
- SS Classic for Floyd Rose
- SS complete bridge assemblies

### Strat-style saddles

Determine the proper string spacing, design & intonation screw position

- The 8000-00 are the more common 2 1/16" spacing, and are usually a great fit for most modern Fender style Tremolos.
- The 8000-F0 (Just remember F for Fat) is what you'll need for the wider, "vintage" 2 3/16" String spaced Fender style Tremolos.

### Tune-o-matic bridges

Check the correlation chart to clarify what is right fit for the majority of TOM bridges on the market.

### Tune-o-matic Sizing Chart

BRIDGE STAMP	STRING SAVER PART	BRIDGE STAMP	STRING SAVER PART
B-2 or B H	PS-8616-00	Jin Ah®	PS-8440-00
Gibson® ABR-01	PS-8400-00	Komax®	PS-8615-00
Gibson® Nashville TOM pre 2000	PS-8501-00	Pigtail® Wraparound	PS-8617-00
Gibson® Nashville TOM post 2000	PS-8500-00	PW	PS-8501-00
GOTOH® Japan	PS-8560-00	S.I.C.	PS-8615-00
Hipshot® Baby Grand	PS-8616-00	TonePros® AVR-II	PS-8615-00
Schaller® 455 / 456	PS-8500-00	TonePros® AVT-II	PS-8501-00
Schaller® made in Germany	PS-8500-00	TonePros® GOTOH	PS-8600-00
SUNG IL®	PS-8616-00	TonePros® TP6	PS-8501-00
SUNG IL® BM002	PS-8615-00	TonePros® TPFP	PS-8502-00
SUNG IL® BM003	PS-8618-00	TonePros® T3BT	PS-8560-00
BR-EG	PS-8633-00	TonePros®	PS-8560-00
Epiphone®	PS-8440-00	ResoMax Tune-o-matic	PS-8501-00

